



Rotary Switch Setting

Position	MIN	50%	MAX
RV1 Operation Intervals (Minutes)	10	35	60
RV2 Operation time (Seconds)	3	6	10

DIP Switch Settings

SW1	1	2	3	4
ON	3-Wire Float	Not In Use	Not In Use	DEMO MODE
OFF	2-Wire Float	Not In Use	Not In Use	Standard Mode



Shabbat Smart Ltd.
 85 Kenilworth Road
 London HA8 8XA
 United Kingdom
 Tel: +44 20 8004 9558
 email: info@ShabbatSmart.com
 www.ShabbatSmart.com

Name:	ShabbatSmart Waste Water Pump Controller	Scale:	NTS
Description:	Single Pump Twin Float	Page:	A4
Version:	1.2	Date:	28/02/2023