


Shabbat/Weekday Switch  
(closed Contact = Weekday Mode)




Backup pump/Alarm Float Switch

Pump Start/Stop Float Switch  
2 or 3 wire option

2/3 Core Cable

2 Core Cable

3 Core Cable



## Sump

### Rotary Switch Setting

Position	MIN	50%	MAX
RV1 Operation Intervals (Minutes)	10	35	60
RV2 Operation time (Seconds)	3	6	10

### DIP Switch Settings

SW1	1	2	3	4
ON	3-Wire Float	Not In Use	Not In Use	DEMO MODE
OFF	2-Wire Float	Not In Use	Not In Use	Standard Mode



Shabbat Smart Ltd.  
85 Kenilworth Road  
London HA8 8XA  
United Kingdom  
Tel: +44 20 8004 9558  
email: info@ShabbatSmart.com  
www.ShabbatSmart.com

<b>Name:</b>	<b>ShabbatSmart Waste Water Pump Controller</b>
<b>Description:</b>	Twin Pump single Float
<b>Version:</b>	1.2

<b>Scale:</b>	NTS
<b>Page:</b>	A4
<b>Date:</b>	28/02/2023