



## Sump

### Rotary Switch Setting

Position	MIN	50%	MAX
RV1 Operation Intervals (Minutes)	10	35	60
RV2 Operation time (Seconds)	3	6	10

### DIP Switch Settings

SW1	1	2	3	4
ON	3-Wire Float	Not In Use	Not In Use	DEMO MODE
OFF	2-Wire Float	Not In Use	Not In Use	Standard Mode

<p>Shabbat Smart Ltd. 85 Kenilworth Road London HA8 8XA United Kingdom Tel: +44 20 8004 9558 email: info@ShabbatSmart.com www.ShabbatSmart.com</p>	<b>Name:</b> ShabbatSmart Waste Water Pump Controller	<b>Scale:</b> NTS
	<b>Description:</b> Twin Pump Twin Float	<b>Page:</b> A4
	<b>Version:</b> 1.2	<b>Date:</b> 28/02/2023